

Type - Tipo - Typ
Type - Tipo

P

Size - Grandezza - Grösse
Taille - Tamaño

412A


Mounting - Montaggio
Montage - Fixation
Tipo de montaje

-F


Ratio - Rapporto
Untersetzung - Reduction
Relación

7.33


Aluminum coaxial gear boxes
Riduttori coassiali in alluminio




M



P



R




B

2 Stages
Riduzioni
Stufen
Trains
Etapas

202A
302A
412A
452A
512A
612A


3 Stages
Riduzioni
Stufen
Trains
Etapas

413A
513A
613A




Without flange / feet

-N



Output flange mounted

-F



Mounted feet

B..




















Feet / piedini

Feet Code	Market reference	G	H	R	L	L1	S
B1	112	18	85	110	87		50
B2	212/3	18	100	130	107.5		
S1	17	18	75	110	90+20		
S2	27	25	90	110	130		
M1	42/3	25	80	110+120	85		
L4	04	13	80	105			
L5	05	16	100	125			

You see feet code in the chart of the dimensions
Vedi codice piede nella tabella delle dimensioni



On request we can deliver our products according to the ATEX
A richiesta possiamo fornire i nostri prodotti secondo le normative ATEX
Auf Anfrage können wir unsere Produkte den Richtlinien ATEX entsprechend liefern
Sur demande nos produits peuvent se conformer à la réglementation ATEX
A pedido, se pueden enviar nuestros productos de acuerdo con las normas ATEX.

Output shaft Albero uscita Abtriebswelle Arbre de sortie Eje en salida	Output flange Flangia uscita Ausgangsflansch Bride de sortie Brida en salida	Motor size - Grandezza motore Motor Größe Grandeur moteur - Tamaño motor	Mounting position Posizione montaggio Einbaulage Position de montage Position de montaje	Input bore Foro entrata Eingangshohlwelle Trou d'entree Eje hueco de entrada	Terminal box position Posizione morsetti Klemmkastenlage Position boîte à bornes Posición caja de bornes
<p>V</p>  <p>STANDARD</p> <p>202A</p> <p>S ⇨ Ø14 B → Ø16 D ⇨ Ø20 V ⇨ Ø25</p> <p>302A</p> <p>S ⇨ Ø14 B ⇨ Ø16 C ⇨ Ø19 D → Ø20 E ⇨ Ø24 V ⇨ Ø25</p> <p>412A 413A</p> <p>B ⇨ Ø16 C ⇨ Ø19 D ⇨ Ø20 E ⇨ Ø24 V → Ø25</p> <p>452A 512A 513A</p> <p>E ⇨ Ø24 V ⇨ Ø25 G ⇨ Ø28 H → Ø30 I ⇨ Ø35</p> <p>612A 613A</p> <p>G ⇨ Ø28 H ⇨ Ø30 I → Ø35 L ⇨ Ø38 M ⇨ Ø40</p>	<p>2</p>  <p>N Senza flangia Without flange</p> <p>202A 302A</p> <p>1 ⇨ Ø120 2 → Ø140 3 ⇨ Ø160 4 ⇨ Ø200</p> <p>412A 413A</p> <p>1 ⇨ Ø120 2 → Ø140 3 ⇨ Ø160 4 ⇨ Ø200 5 ⇨ Ø250</p> <p>452A 512A 513A</p> <p>3 ⇨ Ø160 4 ⇨ Ø200 5 → Ø250</p> <p>612A 613A</p> <p>3 ⇨ Ø160 4 ⇨ Ø200 5 → Ø250</p>	<p>-C</p> <p>Flange Flangia</p>  <p>B5</p> <p>-A=56 (Ø120) -B=63 (Ø140) -C=71 (Ø160) -D=80 (Ø200) -E=90 (Ø200) -F=100 (Ø250) -G=132 (Ø300)</p> <p>Type R Tipo R</p>  <p>202A 413A</p> <p>-1 ⇨ Ø14</p> <p>302A 412A 513A 613A</p> <p>-2 ⇨ Ø19</p> <p>452A 512A 612A</p> <p>-3 ⇨ Ø24</p> <p>Without flange Senza flangia</p>  <p>B14</p> <p>-O=56 (Ø80) -P=63 (Ø90) -Q=71 (Ø105) -R=80 (Ø120) -T=90 (Ø140) -U=100 (Ø160) -V=132 (Ø200)</p> <p>Brushless</p> <p>BB=50/70-M5 BC=60/75-M5 BD=70/90-M6 BE=80/100-M6 BF=95/115-M8 BG=110/145-M8 BH=130/165-M8</p>	<p>B3</p>  <p>B3 STANDARD</p>  <p>B6</p>  <p>B7</p>  <p>B8</p>  <p>V5</p>  <p>V6</p>  <p>V8</p>	<p>ST</p> <p>standard bore foro standard</p> <p>ST</p> <p>COUPLING STANDARD (IEC)</p>  <p>-A = 9mm -B = 11mm -C = 14mm -D = 19mm -E = 24mm -F = 28mm</p> <p>BRUSHLESS *</p>  <p>-2 = 11mm -3 = 14mm -4 = 19mm -5 = 22mm -6 = 24mm</p> <p>-0</p> <p>Ready for input coupling Predisposto per giunto</p>  <p>* With reduction bushing where applicable Con bussola di riduzione dove prevista</p>	<p>With Type M specify terminal box position Con tipo M specificare posizione morsetti</p>  <p>A</p>  <p>B STANDARD</p>  <p>C</p>  <p>D</p>